

# INSTALLATION MANUAL EMERGENCY RELEASE KIT

## SVERK

### shave door handle emergency release kit installation



**IMPORTANT NOTICE:** These instructions are for general reference purposes only. Professional installation is highly recommended.

- 1 Attach the housing inside the door, leaving plenty of slack in the housing for the latch to have full operational travel.
- 2 Route the housing through the door making sure not to put 90 degree bends in the cable.
- 3 Attach the housing with zip ties inside the door. This is done so that the housing doesn't move when the cable is being pulled.
- 4 Run the housing through the door loom and into the fender well. Use billet door loom (DLOOMBL) for a cleaner look.
- 5 Now is the time to determine where the housing will be located in its final installation.
- 6 Once the location is determined, route the housing to that location. \*This is a measuring run, so do not attach the housing.
- 7 Once the housing is where you want it cut it, and feed the cable through the housing.
- 8 Attach the cable to the latch using supplied crimps.
- 9 Now attach the housing in the fender well, again making sure not to put 90 degree bends in the housing.
- 10 Cut the cable approx. 2 inches longer than the housing to allow for the knob to be attached.
- 11 Attach the knob and test the system.

★ **NOTE** ★

- ★ Leave plenty of slack in the housing to allow for the door to open and close properly.
- ★ No 90 degree bends in cable housing.

\*Instructions are not vehicle specific. For general reference purposes only.

