

**Design Engineering, Inc.**

604 Moore Road  
Cleveland, OH 44012



*THERMAL TUNING PRODUCTS*

**Installation Instructions**

**DEI Cool Cover™ Air Tube Kit**

PART NO. 010417

KIT CHECKLIST	
1	Air Tube Reflective Wrap
1	Strip of Reflective Tape

NOTE
It may be necessary to cut wrap for proper length fitment. You will need a sharp knife, razor, or sissors, and a pen with straight edge.

**DIRECTIONS**

- 1 - Remove and disconnect air tube from motor bay if installed on vehicle.
- 2 - Test Wrap the air tube that will be wrapped to get an idea for proper and secure fitment.
- 3 - Using a pen and straight edge, mark the areas that will be removed.  
\*Don't forget to incorporate emissions or vacuum line(s) as well as various brackets.
- 4 - For better asthetics, use the reflective tap to accent any cut edges.
- 5 - Simply apply half the tape on the edge of the cut material and fold over to opposite side.
- 6 - When desired look is achieved, securely fasten wrap with the velcro strip, connect and install airtube back into motor bay.



\*Univeral Product, may require some modification depending on application