

# SCOOP INSTALLATION INSTRUCTIONS

## Parts Included:

1Pc – Hood Scoop	2Pcs – Air Cleaner Top
2Pcs – Double Barrel Butterfly Flap	2Pcs – Air Cleaner Base Mounting Flange
1Pc – Double Barrel Linkage Bar	2Pcs – Air Filter Element
1 – Linkage Bar Mounting Kit	2Pcs – Air Cleaner Stud (¼"-20 x 6")
1Pc – Single Carb Adapter Plate	2Pcs – Wing Nut (¼"-20)
4Pcs – Cap Screw (8-32 x ¾")	4Pcs – Lock Nut (8-32)
8Pcs – Hex Head Bolt (¼"-20 x ½")	

## INSTRUCTIONS:

1. Remove the existing air cleaner from carburetor.
  2. Install butterfly flaps by using linkage bar and mounting kit.
  3. Screw 6" stud(s) into the carburetor(s). Check length of stud(s) with air scoop clearance. Cut stud(s) to desired length if necessary.
  4. Set the air cleaner base mounting flange(s) onto the carburetor. Place air filter element(s) and air cleaner top(s) onto to the base mounting flange(s).  
Use the ¼"-20 wing nut(s) to tighten entire assembly to the carburetor(s).
- NOTE: For a single carburetor, place single carb adapter plate onto base mounting flange before placing air filter element and air cleaner top.*
5. Place scoop onto the base flange(s) and secure using ¼"-20 x ½" hex head bolts. Double check to make sure all bolts and nuts are tight.

*Tech Tip: Whenever working around open carburetors, be extremely careful not to drop anything into the carburetors. Doing so will cause that foreign object to enter the intake manifold which can cause serious damage to your engine.*