



ALL NEW WIRING HARNESSES

FOR AIR-COOLED VOLKSWAGENS



Every EMPI Wiring Harness includes:

- Comprehensive, easy to follow installation instructions.
- Correct gauge and wire color with coded stripes for trouble-free matching to the factory wiring diagram.
- Branch wires are packaged individually and numbered for ease of identification and installation.
- Factory style connectors.



EMPI has taken the grief out of re-wiring your next project! Our Engineering Team has created an all new, high quality reproduction of the factory German wiring harness with correct color coding. Ready to install right out of the box!

Part Numbers Now Available and In Stock:

| PART NUMBER | APPLICATION |
|------------------|------------------------|
| 98-9482-0 | 62-64 Sedan |
| 98-9488-0 | 70-71 Sedan |
| 98-9484-0 | 1965 Sedan/Conv |
| 98-9476-0 | 58-59 Sedan |
| 98-9485-0 | 1966 Sedan/Conv |
| 98-9486-0 | 1967 Sedan/Conv |

Initial applications include the 1958 through 1971 model year Beetles and Super Beetles with additional year and model coverage **COMING SOON!**