

Design Engineering, Inc.

604 Moore Road
Cleveland, OH 44012



THERMAL TUNING PRODUCTS

Installation Instructions

DEI Lite'N Boltz™

PART NO. 030301 through 030311

KIT CHECKLIST	
2	Lite'N Boltz
2	Nonlighted Boltz (kit only)

NOTE
Great for motorcycles where space is limited!

DIRECTIONS

- 1 - Disconnect vehicle battery before starting.
- 2 - Remove the nylon nut off the lighted bolts and remove old license plate / bolts.
Feed wire through existing hole where previous bolt was located, make sure to feed the
- 3 - wire through the license plate holes as well. On the back side, take the nylon nut and feed the wires through the center then tighten nylon nut on the Lite'N Bolt.
Polarity of the wires are nonspecific. Connect the wires of the Lite'N Bolts to the existing
- 4 - license plate light. One wire should go to positive and one should go to negative. Please note that the negative maybe a chassis ground as well.
- 5 - Seal any exposed wires with electrical tape and reconnect battery.

