



NOTE:

- ① The red power line (+, positive) of the compressor should be connected to any one terminal of the pressure switch.
- ② The red power line (+, positive) with fuse should be connected to the other terminal of the pressure switch.

