



Jeep Grand Cherokee 93-98 ZJ 4" Suspension Kit

Thank you for choosing Rough Country for all your suspension needs.

Rough Country recommends a certified technician install this system. In addition to these instructions, professional knowledge of disassemble/reassembly procedures as well as post installation checks must be known. Attempts to install this system without this knowledge and expertise may jeopardize the integrity and/or operating safety of the vehicle.

Please read instructions before beginning installation. Check the kit hardware against the parts list on this page. Be sure you have all needed parts and know where they go. Also please review tools needed list and make sure you have needed tools. Always wear safety glasses.

PRODUCT USE INFORMATION

As a general rule, the taller a vehicle is, the easier it will roll. Seat belts and shoulder harnesses should be worn at all times. Avoid situations where a side rollover may occur.

Generally, braking performance and capability are decreased when larger/heavier tires and wheels are used. Take this into consideration while driving. Do not add, alter, or fabricate any factory or after-market parts to increase vehicle height over the intended height of the Rough Country product purchased. Mixing component brands is not recommended.

Rough Country makes no claims regarding lifting devices and excludes any and all implied claims. We will not be responsible for any product that is altered.

Due to inconsistency of vehicles when manufactures and various options available, the amount of actual lift gained by this lift kit could vary.

This kit features Rough Country's adjustable joint design. Adjustable end tool is included in kit. Assemble the joints per the separate instruction sheet Part # 92RCJ120 provided.

This suspension system was developed using a 31 x 10.50 x 15 tire with factory wheels. After market wheel will fit with 3 5/8" back spacing. Larger tire and wheel combinations may increase leverage on suspension, steering and related components. Consider the additional stress you could be adding on the OE components, when selecting combinations larger than OE.

NOTICE TO DEALER AND VEHICLE OWNER

Any vehicle equipped with any Rough Country product should have a "Warning to Driver" decal installed on the inside of the windshield or on the vehicle's dash. The decal should act as a constant reminder for whoever is operating the vehicle of its unique handling characteristics.

TORQUE SPECS:

Size	Grade 5	Grade 8
3/8"	30 ft/lbs	35 ft/lbs
7/16"	45 ft/lbs	60 ft/lbs
1/2"	65 ft/lbs	90 ft/lbs
9/16"	95 ft/lbs	130 ft/lbs
5/8"	135 ft/lbs	175 ft/lbs
	Class 8.8	Class 10.9
8MM	18ft/lbs	23 ft/lbs
10MM	32ft/lbs	45ft/lbs
12MM	55ft/lbs	75ft/lbs
14MM	85ft/lbs	120ft/lbs

TOOLS NEEDED:

13mm wrench	13/16" Socket
13mm socket	9/16" Socket
15mm wrench	7/16" Drill Bit
15mm socket	T55 Torx Head
16mm socket	T50 Torx head
18mm socket	Jack stands
18mm wrench	Safety Glasses
21mm wrench	Drill
21mm socket	WD40
19mm wrench	Coil Spring Compressor
19mm socket	
17mm wrench	
Floor Jack	

KIT CONTENTS



Kit Contents:

9288-Front Coil Springs

9289-Rear Coil Springs

1687 Kit Box Including:

- 4-Lower Fr & Rr Adjustable Arms (A)
- 2-Adjustable Rear Upper arms (B)
- 2-Front Sway Bar Links (C)
- 2-Front Sway Bar Link Brackets (D)
- 1-Rear Track Bar Bracket (E)
- 2-Rear Sway Bar Brackets (F)
- 2-Rear Bump Stop Brackets (G)
- 2-Front Bump Stop Spacers (H)
- 1-Rear Brake Line Bracket (I)
- 1-Sway Bar Bushing Bag
- 1-Rear Track Bar Bag


1687N2 Box containing:

Fr Shock-#658693 (J)

Rr Shock-#658692 (K)

FRONT INSTALLATION

1. Place the vehicle on a level surface. Set the parking brake. Center the front wheels and chock the rear wheels
2. From inside the engine compartment, using a 13mm deep well socket, remove the upper stud nut, washer and bushings from the front shocks. **See PHOTO 1.**
3. Jack up the vehicle and place jack stands on the frame rail behind the lower control arm mount.
4. Remove the front tires/wheels, using a 13/16 deep well socket.
5. Place a floor jack underneath the axle for support and remove the lower shock bolts from the front shocks using a 13mm socket and wrench. Retain the factory lower bolts for reuse. **See PHOTO 2.**



6. Using a 15mm wrench and 18mm wrench for the upper bolt and a T55 torx head for the lower bolt, remove the sway bar links. **See PHOTO 3.**
7. Remove the lower track bar bolt on the axle side using a 15mm socket. Retain the factory hardware for reuse. **See PHOTO 4.** Measure over 3/4" , mark and drill using a 7/16" drill bit.



8. Using a 13mm wrench remove the driver and passenger side coil retainer. Lower the axle and remove the coil spring. A coil spring or strut compressor may be needed to remove the stock coil. Pull the ABS sensor wire from the stock mount. Spray the line with WD40 to allow the mount on the wire to slide, then re-attach. **See PHOTO 5.**
9. Mark the original position of the eccentric cams on lower control arm. Using a 21mm socket & 18mm wrench remove the stock lower bolt from the axle. Using a 21mm socket and wrench, remove the frame bolt from the lower control arm. Retain the factory hardware for reuse. **See PHOTO 6.**
10. Using a 15mm socket and t50 torx head, loosen the upper control arm.



11. Adjust the arm to 16 1/2". The straight male end goes to the frame mount, offset end mounts up on the axle. Using a 21mm socket and 18mm wrench install the lower control arm in the axle mount. Using a 21mm wrench and socket install the control arms in the frame mount, using stock hardware. Do not tighten at this time. **See PHOTO 7 & 8.**
12. Using a 9/16" wrench and the 3/8" x 3.5" self tapping bolt from 1687 bag2. screw bolt into the center of the coil spring plate to tap a hole for the bump-stop to be installed in the next step.




13. Install the new coil spring, with the nylon bump-stop and bolt from the above step in coil. A coil spring or strut compressor will be needed to install the new coil spring. Install the new spring into the upper and lower coil spring seat. Make sure the coil spring is seated properly on the coil seat, by rotating the spring until the pigtail end fits into the spring pocket. Using a 9/16" wrench secure the bump-stop back in place. **See PHOTO 9.** Install the coil spring clip using a 13mm wrench. Torque to 16ft/lbs.



14. Install the new sway bar hoop on the sway bar where the stock link was secured, using the supplied 3/8" x 1 1/4" bolt and flange lock nut. **See PHOTO 10.** Install the bushings and 12mm sleeves on the top and bottom of the sway bar link at this time. Install the upper part of the new link in the hoop bracket with the 12mm bolts, washers and nuts. Install the lower link in the stock mount with the 12mm bolts, washers and nuts. Hardware is in 1687Bag1. Tighten using a 18mm and 19mm wrench. **See PHOTO 10 & 11.**



14. Install the track bar in the axle mount location as shown in **PHOTO 12**. Install the stock bolt in the upper hole and tighten. Assemble the front shock absorbers, part # 658693 and install using the factory hardware on the bottom of the shock. Torque to 20 ft/lbs, Install the upper stud bushings and tighten the upper mounting point until bushing swells slightly Repeat for opposite side.
15. Install the tires/wheels and lug nuts, using a 13/16" deep wheel socket. Lower the vehicle to the ground.
16. Tighten the lower control arms, using a 21mm socket and 21mm /18mm wrench. Torque to 130 ft/lbs. **Note** Make sure flex joint housing is centered in mount before tightening jam nut. Should not be touching either side.****




REAR INSTALLATION

1. Chock the front wheels. Jack up the rear of the vehicle and support the vehicle with jack stands, so that the rear wheels are off the ground.
2. Remove the rear tires/wheels, using a 13/16" deep well socket. Place a floor jack under the differential.
3. Remove the rear track bar from the frame mount on the passenger side using a 18mm wrench and T55 torx head. Loosen the track bar on the axle side using a T55 and 18mm wrench.
4. Using a 18mm socket and a 15mm wrench, remove the rear shocks. Retain the shock hardware for reuse.
5. Using a 15mm socket disconnect the sway bar bracket from the frame. **See PHOTO 1.**
6. Using a 13mm wrench remove the coil spring retainer. Retain factory hardware.
7. Lower the axle and remove the stock coil spring. A coil spring or strut compressor may be needed to remove the stock coil.
8. Using a 21mm socket and wrench remove the lower control arm. Retain the factory hardware.
9. Adjust the lower arm to 17 1/2". Using a 21mm socket and wrench install the lower control arm using factory hardware. Do not tighten at this time.
10. Using a 15mm socket, wrench and a T50 torx head, remove the upper control arm. Using a 13mm wrench unbolt the brake line bracket from the upper control arm. **SEE PHOTO 2.** Retain the factory hardware.



11. Adjust the upper arms to a length of 14 1/8". Using a 15mm wrench, socket and T50 install the upper control arm using factory hardware. Do not tighten at this time. Using a 13mm wrench, reinstall the brake lines to the control arm with the supplied bracket as shown in **PHOTO 3.** Secure the brake line bracket to the arm with supplied 5/16" x 3/4" bolts, nuts & washers.
12. Pull the stock rear bump stop out of the mount. Using a 13mm socket, unbolt the 2 bolts holding the bracket to the frame. Using the 2-8mm x 70mm bolts from 1687bag2, install the bump stop extension bracket along with the stock bracket to the frame. Reinstall the factory bump stop. **See PHOTO 4.**



13. Install the new coil spring. A coil spring or strut compressor will be needed to install the new coil spring. Install the new spring into the upper and lower coil spring seat. Make sure the coil spring is seated properly into the coil seat, by rotating the spring until the pigtail end fits the spring pocket. Install the coil spring clip using a 13mm wrench, Torque to 16ft/bs.
14. Install the new sway bar drop brackets in between the frame and the sway bar mount as shown in **PHOTO 5.** Using the 10mm x 55mm bolts and washers supplied in 1687bag1. Tighten using a 17mm wrench.

15. Assemble the new shocks part #658692 with sleeves. Install the shock into the factory location using the stock hardware. Tighten using a 15mm and 18mm socket. Tighten the upper to 25 ft/lbs and the lower to 55 ft/lbs.
16. Install the new track bar bracket into the stock frame mount on the passengers side. Using the 7/16" x 1" bolt, washer and nut from 1687bag2, using a 16mm socket and wrench. Bolt the new bracket to the mount. Insert the sleeve from 1687bag2 into the new bracket and insert the 12mm x 65mm bolt, washer through the bracket and sleeve where the track bar was bolted stock. Tighten using a 19mm wrench and socket. Flip the track bar from end to end and install into the new bracket and axle bracket with the stock track bar bolts.. Using a T55 and 18mm wrench torque to 50ft/lbs. **See PHOTO 6 & 7.**
17. Install the tires/wheels and lug nuts. Using a 13/16" deep well socket. Lower the vehicle to the ground.
18. Tighten the lower control arms to 130ft/lbs using a 21mm socket and wrench. **Note** Make sure flex joint housing is centered in mount before tightening jam nut. Should not be touching either side.****
19. Thoroughly grease all zerk fittings in the suspension links.



POST INSTALLATION

1. Check all fasteners for proper torque. Check to ensure there is adequate clearance between all rotating, mobile, fixed and heated members. Check steering for interference and proper working order. Test brake system.
2. Perform steering sweep. The distance between the tire sidewall and the brake hose must be checked closely. Cycle the steering from full turn to full turn to check for clearance. Ensure there is adequate clearance between exhaust and brake line, fuel lines, fuel tank, and wiring harnesses. Failure to perform inspections may result in component failure.
3. Check clearance between the inner side wall of tires and links. It may be necessary to adjust steering stops.
4. Re torque all fasteners after 500 miles. Visually inspect components and re torque fasteners during routine vehicle service.
5. Readjust headlights to proper settings.
6. Vehicle will have to have an alignment.
7. Some vehicles may experience drive line vibrations. Angles may require tuning, shafts may need to be lengthened or trued, and u-joints may need to be replaced.

MAINTENANCE INFORMATION

It is the ultimate buyers responsibility to have all bolts/nuts checked for tightness after the first 500 miles and then every 1000 miles. Wheel alignment steering system, suspension and driveline systems must be inspected by a qualified professional mechanic at least every 3000 miles.